

## ASBESTOS ROOF SURFACES

## APPLICATION GUIDE

Ensure compliance to all Local Government regulations in relation to Asbestos handling. Local Government regulations may make adequate preparation impossible, therefore, Globalcote is unable to provide a product warranty.

**STERILISE:** Prior to coating the surface, *Prepcote Surface Treatment* is applied to sterilise fungal and algae growth. Inadequate application will void any warranty.

Spray one (1) flood coat of *Prepcote* to the surface with an atomising gun. Allow 4 hours prior to coating with the *Primecote Sealer Primer*. Please note that *Prepcote Surface Treatment* is not a cleaning product, it is to remain on the surface to form part of the Globalcote system.

**SURFACE SEALED:** To ensure maximum adhesion the entire roof area needs to be thoroughly coated with *Primecote Sealer Primer* – 2 coats at a spread rate of 4m<sup>2</sup> per litre, per coat.

Once suitably primed there should be a visible shine evident on the surface.

**1st COAT:** 1st coat of *Globalcote Membrane* is applied at a spread rate of 5m<sup>2</sup> per litre.

**2nd COAT:** 2nd coat of *Globalcote Membrane* is applied at a spread rate of 5m<sup>2</sup> per litre.

Weather conditions must be considered and deemed suitable before proceeding with application of the Globalcote system. Do not apply where rain is imminent. Varying temperatures and high humidity may affect curing times.

## HEALTH &amp; SAFETY

- **Contact Poisons Information Centre (Phone Australia: 13 11 26) or a doctor.**
- **IF SWALLOWED:** Rinse mouth. Do NOT induce vomiting.
- **IF ON SKIN:** Wash with plenty of soap and water.
- **IF INHALED:** Remove victim to fresh air and keep at rest in a position comfortable for breathing.
- **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- **IF EXPOSED OR CONCERNED:** Get medical advice/attention.
- Wear appropriate protective clothing, gloves, eye/ face protection and suitable respirator.

## RECOMMENDATIONS &amp; PRECAUTIONS

- Use this product in a well-ventilated area.
- Ensure that the application of the product is in accordance with Globalcote recommendations.
- Due care and consideration should be taken where water collection methods are present. Globalcote recommends allowing 10 days curing and an initial rinse (rain or tap water wash) prior to reconnecting water collection systems.
- The surface preparation is the responsibility of the Builder, Renovator, Contractor or Applicator. It is also the responsibility of the Applicator to ensure that the substrate is of an acceptable standard prior to the application of the Globalcote Coating System.

**DISCLAIMER:** The recommendations and data provided in this document are true and accurate at the time of testing. The information is given in good faith but without any guarantee as conditions and methods of use on the Globalcote product are beyond Globalcote's control. Globalcote recommends that the applicator of this product conducts a small test patch in an inconspicuous area to determine the suitability of the Globalcote material and its recommendations prior to use or application.